



Number	Name
1	FRONT COVER
2	STEEL BALL BRACKET
3	RETAINING RING 27.5*2
4	WASHER 30X48.5X3
5	CUSHION WASHER
6	HOLDING SLEEVE
7	KEY
8	HOLDING RING
9	SPRING 2.5X55X90.5
10	ANGLE TRANSFER BLOCK
11	ROTATING SLEEVE
12	INNER SOCKET BOLTM8X30
13	SPRING WASHER 8
14	STEEL BALL 6.35
15	STEEL HEAD
16	O RING
17	SPRING RETAINING RING FOR HOLE 41
18	OIL SEAL 32*42*7
19	CONNECTING SLEEVE
20	O RING
21	STRIKER COVER
22	O RING 22*11
23	ANGLE GUIDE RING
24	CYLINDER FIXING BASE
25	GEAR BOX COVER
26	STRIKER
27	O RING 32.2*5
28	CYLINDER
29	GUIDE SLEEVE
30	SPRING 2.5X52.5X127
31	PISTON PIN 10X38
32	PISTON

Number	Name
33	CONNECTING ROD
34	GEAR BOX
35	ECCENTRIC SHAFT
36	WASHER AS1730
37	NEEDLE ASS'Y 163032.5
38	OIL COVER
39	O RING
40	WOOL RING
41	WAHSER 6X18X1
42	SELF SCREW ST4*12F
43	SCREW M5*16
44	GEAR BOX COVER
45	O RING 79.6X2.8
46	SELF SCREW ST4.8X30
47	NEEDLE BEARING F-225538-1
48	SPRING RETAINING RING FOR HOLE
49	OIL SEAL 20X32X6.3
50	MOTOR HOUSING
51	SELF SCREW ST4.8*60
52	STATOR
53	Oil seal ring
54	STEEL SLEEVE
55	ARMATURE
56	BEARING BASE
57	BALL BEARING 6200-2RS
58	SPRING RETAINING RING
59	O RING 30*2
60	BRUSH HOLDER BASE
61	SWIRL SPRING
62	SCREW ST3.5*12F
63	CARBON BRUSH
64	BRUSH HOLDER

Number	Name
65	CARBON BRUSH SPRING SLICE
66	BAFFLE PLATE
67	REAR COVER
68	FIXING NUT
69	SELF SCREW ST4.8*30
70	PROTECTING COVER
71	INDICATION LIGHT
72	ADJUSTING SWITCH
73	SIDE COVER
74	ANTI-VIRBRATION SLEEVE
75	ANTI-VIRBRATION BLOCK
76	FLAT WASHER 5
77	SCREW M5*50
78	SPRING WASHER 5
79	SELF SCREW ST4.8*25F
80	LEFT HANDLE
81	SWITCH
82	CORD GUARD
83	CORD RELIEF
84	CORD
85	SCREW ST4.8*45F
86	RIGHT HANDLE
87	SCREW ST4*16F
88	OUTER HEX. BOLT M8*150
89	HOLDING HOOP
90	CLIPPING BLOCK
91	HANDLE CLIP
92	HANDLE KNOB
93	NUT M8
94	HANDLE KNOB COVER
95	SIDE HANDLE