



Number	Name
1	Cross groove Screw M5x40
2	Cross groove Screw M5x45
3	Flat gasket ř5
4	Spring gasket ř5
5	Hexagon Nut M5
6	Left-outsider Wheel Cover
7	Middle Cover
8	Left hexagon Nut M12
9	Cross Groove Screw M5x15
10	Wheel Flange
11	Scrip shim
12	Grindstone
13	Cross Groove Screw M4x10
14	Cross Groove Screw M5x10
15	Left-inside Wheel Cover
16	Bearing Housing
17	Base
18	Condenser
19	Base plate
20	Rubber Grommet
21	Grindstone
22	Ball Bearing
23	Rotor
24	Stator
25	Casing
26	Switch
27	Right-inside Wheel Cover
28	Hexagon Nut M12
29	Right-Outsider Wheel Cover