



Number	Name
1	Output shaft
2	6000 bearing
3	big gear
4	turbine
5	607 bearing
6	motor teeth
7	6001 Bearing
8	Cross recessed pan head ST4.2X12-F
9	oil pump
10	Brushless motor left housing
11	Brushless Motor Gearbox Cover
12	4820 brushless motor
13	Brushless motor right housing
14	Cross recessed pan head ST4.2X16-F
15	Cross recessed pan head ST4.8X14-F
16	right case
17	Battery Adapter - Right
18	Cross recessed pan head ST4.2X35-C
19	front handle
20	Tension Adjustment Knob
21	Tension adjustment drive gear
22	Guide plate locking knob
23	side cover
24	tension adjustment column
25	Tension adjustment screw
26	Tensioning Adjustment Passive Gear
27	side cover positioning
28	chain
29	Guides
30	wood teeth
31	brake cover
32	10MM shaft circlip
33	Sprocket spacer
34	Brake belt
35	brake drum
36	3X8.5 cylindrical pin

Number	Name
37	Micro Switch
38	brake spring
39	hinge head
40	hinge connection
41	3X8.5 cylindrical pin
42	hinge tail
43	leaf spring
44	5X40 cylindrical pin
45	brake pads
46	left case
47	Anti self-locking switch
48	oil can
49	Oil can lid rubber ring
50	oiler lid
51	hook
52	Hose connector
53	intake nozzle
54	oil outlet
55	Inlet pipe
56	controller
57	battery pack pins
58	battery pack
59	Battery Adapter - Left