



Number	Name
1	HEX SCREW
2	OUTER FLANGE
3	INNER FLANGE
4	P.H SCREW
5	SPRING WASHER
6	FLATNESS WASHER
7	HEAD COVER
8	SHAFT RETAINING RING
9	WHEEL GUARD
11	HOOK SPRING
12	CARRIAGE BOLT
13	LOCKNUT
14	BASE
15	P.H. SCREW
16	SPINDLE
17	CROSS DEEP HEAD SCREW
18	FRONT COVER
19	BALL BEARING 6203-2Z
20	WASHER FOR THE HOLE
21	STEEL SLEEVE
22	HALF CIRCLE KEY
23	BIG GEAR
24	SHAFT RETAINING RING
25	NEEDLE BEARING
26	P.H.SCREW
27	RUBBER BLOCK
28	TAPPING SCREW
29	WASHER
30	TAPPING SCREW
31	HEAD CASE
32	ORIENTATION PIN(RUBBER MATERIAL)
33	BEARING BEARING 6201-2RS
34	FLATNESS WASHER
35	GROOVE NUT
36	DEPTH ADJUSTING LEVER
37	P.H. SCREW
38	SHAFT LOCK LEVER
39	ARMATURE
40	BALL BEARING
41	TAPPING SCREW
42	WASHER
43	BAFFLE PLATE
44	STATOR
45	WAVE WASHER
46	NUT
47	HANDLE COVER(RIGHT)
48	SWITCH
49	TAPPING SCREW
50	TAPPING SCREW
51	STRAIN RELIEF
52	MOTOR HOUSING

Number	Name
53	P.H. SCREW
54	BRUSH HOLDER CAP
55	CARBON BRUSH
56	BRUSH HOLDER
57	CORD GUARD
58	CORD
60	RULER GUIDE
61	SIDE GRIP (Anti-vibration(screw11/7)
62	SIDE GRIP (Simple(screw11/7)
63	hex wrench m8
64	ROTOR FAN
	blade