


# F30 ELECTRIC BRAD NAILER 7531






## **TECHNICAL SPECIFICATIONS**

Model	7531		
Power	2200W		
Voltage	220-240V		
Frequency	50-60Hz		
Nb of Shots/Min	35Shots/Min		
Maximum Magazine Capacity	100		
Max Nail Length	10-30mm		
Gauge	18Gauge		
Weight	1.36Kg		
Includes	Hex. Wrench M3, Hex.Wrench M4, Blade		

## **PART LIST**






#### *ELECTRIC STAPLER*

is a new kind convenient tool for room decorations, furniture and wooden box. It is convenient to carry and work more efficiently than pneumatic gun, also with low noise.


#### -INSTALL STAPLES

Make sure the stapler power off before installing.


1- Press down the magazine latch and make it move back.



2- Put down the nail and staples in the magazine.



3- Closed the magazine, make sure it in the right position.





The magazine may be overload if the lid can not close, please try again after remove some nails or staples.




## **■**operation method


If you want to use the tools, please attention.

1- Check the power switch, let the power switch to "o" position. (used


before)



- 2- Connect the power with wall switch or power socket.
- 3- Please move power switch to "I" position. The indicator light will light up.




4- Put the nails/staples in the magazine. And close the magazine.




5- Point the nail gun at wooden surface






6- Press the switch and shot the nails or staples at right position.



7- If you work finish, please move the power switch to"o" position, the indicator light will turn off.




8- Disconnect the power, and open the magazine to take out the staples or nails.

### **FAILURE RECOVERY**


Clare the be jam nails or staples, make sure the machine must be turn off before the fallowing works.



## 1- Remove 3pcs screw at head



2- Remove the nails or staples which may cause a jam.



- 3- Electric stapler safety warning:
- Electric stapler is not a toy, so put it out of children reach.
- Electric stapler mis operation may cause unexpected personal injury
- Do not point the electric stapler an yourself our other people.
- Do not turn on the electric stapler, unless you are and safety environment.
- Please turn off the power when your clean the electric stapler.
- Do not use electric stapler wire for other machine ,may cause electric shock of fire.

