



Number	Name
1	Quick change sleeve snap ring
2	Quick change sleeve snap ring
3	Quick change spring
4	Quick change of head
5	Quick pack
6	Skull
7	O-ring
8	axle sleeve
9	Washer
10	"Quick change steel ball for batch head 3.5"
11	output shaft
12	Impact assembly
13	planet gear
14	Planetary gear pin
15	Gear pin gasket
16	Inner ring gear
17	Deep groove ball bearing 6801
18	Pan head screw m3x8
19	Gearbox
20	O-ring
21	Motor gear
22	MOTOR
23	U-type clasp
24	Cross tapping screw 2.9x16
25	Casing
26	Reversing lever
27	switch
28	Power display lamp cover
29	Led transparent cover
30	Battery pack
31	Charger
32	Battery pack