



Number	Name
1	Auxiliary handle
2	Cross pan head combination screw
3	Flat washer
4	Adjusting knob
5	Steel ball
6	Adjusting spring
7	Guide plate cover
8	Adjusting screw column
9	Adjusting screw
10	Adjusting the large teeth
11	Adjusting the small teeth
12	Adjusting screw baffle
13	Adjusting screw gland
14	Cross pan head pointed tapping screw
15	Outer hexagon flange nut
16	Chain
17	Guide plate
18	Cross pan head pointed tapping screw
19	Baffle
20	Spring
21	External retaining ring
22	Sprocket
23	Left casing
24	Left casing pin
25	Outer hexagonal bolt
26	Output shaft
27	Large tooth
28	Brushless stator
29	Toothlet

Number	Name
30	Rotor
31	Deep groove ball bearing
32	Cross pan head pointed tapping screw
33	Middle cover
34	Oil outlet nozzle
35	Tubing
36	Oil pump assembly
37	Left and right paddles
38	Switch
39	Battery display board
40	Makita pin
41	Right casing pin
42	Deep groove ball bearing
43	Oiler
44	Upper right casing
45	Battery pack
46	Charger

8658

20V Brushless Cordless Chain Saw 20cm