

www.ronixtools.com

BRUSHLESS

Number	Name
1	Screw
2	Floor
3	Nut
4	Saw screw
5	Upper Plate
6	Circlip
7	Activity shield
8	Saw bit
9	Tooth screw
10	Pressure plate
11	Gearbox assembly
12	Bearing
13	Mobile shield handle
14	Long screw
15	Gasket
16	Screw sleeve
17	Nut
18	Base angle adjustment
19	E-type card spring
20	Angle Adjustment Button
21	Cover block
22	Fixed cover
23	Left case
24	Switch
25	Push rod
26	Control panel
27	Shaft lock insert
28	Motor
29	Tail cover bracket
30	Tail cover
31	Right shell
32	Battery pack

8902

Cordless Brushless Circular Saw 20V