



Number	Name
1	Screw 5*16
2	Washer
3	O-Ring 16*1.7
4	Exhaust Cover
5	Washer
6	Screw 6*30
7	Washer #6
8	Cylinder Cap
9	Gasket
10	Washer
11	Seal,Air/ Stopper
12	Feeder Spring
13	O-Ring 40*2.65
14	O-Ring 56.7*2.9
15	Firing Valve Piston
16	Washer
17	Seal,Air/ Stopper
18	O-Ring 44.7*3.5
19	Piston head
20	Driver Blade
21	O-Ring 80*2.65
22	Spacer
23	O-Ring 54*3
24	Cylinder
25	Bumper
26	Nozzle
27	O-Ring 16*1.8
28	O-Ring 19*2.4
29	Trigger Valve Guide
30	O-Ring 5.6*1.9
31	Air Plug
32	O-Ring 8.2*1.78

Number	Name
33	Trigger Valve Guide
34	O-Ring 2.3*1.4
35	Feeder Spring
36	Remote Core
37	Seal, Air
38	Flake
39	Feeder Spring
40	Release Catch
41	Prevent Fall Frame B
42	Prevent Fall Frame B
43	Spring Pin 3*30
44	Body
45	PIN
46	Releasing Blade
47	Spring Pin 3*17
48	PIN 3*14
49	Trigger
50	Feeder Spring
51	Trigger
52	Washer
53	Screw 4*8
54	Spacer
55	Handle Grip
56	Screw 6*20
57	Tail Cover
58	Trigger Valve Set
59	Screw 4*10
60	Washer #4
61	Nut M6
62	Prevent Fall Frame A
63	Prevent Fall Frame A
64	Driver Guide

Number	Name
65	Screw 5*20
66	Driver Guide Cover
67	Screw 5*12
68	Pusher
69	Stopper
70	Magazine Support
71	Stopper
72	Magazine Support
73	Nail Tank
74	Steel Bar
75	Feeder Spring
76	Click Lever
77	Feeder Spring
78	Spring Pin 3*17
79	Tail Cover
80	Screw 5*10
81	Screw 4*8
82	Upper Mag
83	Piston Set
84	Cylinder Set
85	Magazine Set