


Number	Name
2	alternator fan cover
3&4	Alternator (including rotor and stator)
5	alternator protect belt
6	alternator End Cover
7	5kw AVR
8	Carbon Brush
9	terminal plate
10	rotor bolt
11	rotor flat washer
12	rotor centre bolt
13	5KW alternator or sleeve
14	rear cover
15	air filter stay
16	ex.pipe gasket
17	exhaust pipe
18	unitary muffler stay
19	unitary muffler
20	genset fuel tank cover
21	oil filter
22	oil gauge assembly
23	fuel tank
24	tubing clip
25	fuel pipe
26	fuel switch
27	protective bar
28	shocking absorb pad
29	fuel tank liner
30	fuel tank damping gasket
	Handle & wheels (31-36, 39,40)
37	guide plate sleeve
38	vibrating rod damping block
41	rubber cone-shaped sleeve

Number	Name
42	european socket
43	circuit breaker
44	earthing bolt essy
45	indicator lamp
46	voltmeter
47	V type DC socket
48	current switch
49	electric switch
41	inlet gasket
42	connecting block
43	carburetor gasket
44	carburetor assy
45	air cheaner gasket
46	air cheaner assy
47	nut M6
48	intake valve
49	exhaust valve
B1	Flange bolt GB5789
B2	Spring Washer GB/T93
B3	flange bolt
B4	Spring Washer GB/T93
B5	Flange nut GB6177
B6	Flange bolt GB5789
B7	Spring Washer GB93
B8	hex nut GB/T6170
B9	Flange bolt GB5789
B10	Flange bolt GB5789
B11	flat washer GB/T97.2
B12	Flange bolt GB6177
B13	Flange bolt GB5789
B14	flat washer GB96
B15	cross truss head topping screws

Number	Name
B16	metal Flange bolt GB/T6187
B17	flat washer GB97.2
B18	flat washer GB96
B19	Flange bolt GB5789



Number	Name
1	bolt M8x38
2	oil seal 35x52x8
3	crankcase cover
4	oil filler cap
5	case cover packing
6	dowel pin φ8x14
7	piston pin clip
8	rod assy connecting
9	piston pin
10	piston
11	piston ring set
12	radial ball bearing
13	camshaft assy
14	crankshaft
15	radial ball bearing
16	balance shaft
17	washer
18	governor gear
19	governor shaft
20	lock nip
21	governor kit
22	flange bolt M6x12
23	oil sensor
24	tappet
25	push rod
26	push rod guide plate
27	valve rocker
28	Crankcase
29	drain plug gasket
30	drain plug bolt
31	dowel pin
32	cylinder head gasket

Number	Name
33	intake valve
34	exhaust valve
35	bolt M8x34
36	cylinder head comp
37	lead wind cover
38	stud bolt M10x80
39	exhaust valve spring seat
40	Valve Guide pipe oil
41	valve spring
42	Exhaust valve seat
43	valve rotator
44	head cover packing
45	head cover comp
46	stud bolt
47	String ring
48	starter motor
49	stud bolt M8x35
50	diode
51	bolt M6x8
52	charging coil
53	bolt M6x30
54	Wire Clamp
55	flywheel comp
56	ignition coil
57	flange bolt
58	cooling fan
59	starter pulley
60	flywheel special nut M16x1.5
61	fan hood
62	recoil starter
63	spark plug(4197)
64	flange bolt M6x8

Number	Name
65	inlet gasket
66	connecting block
67	carburetor gasket
68	carburetor assy
69	air cleaner gasket
70	nut M6
71	air cleaner assy
72	breather tube assy
73	governor arm shaft
74	Oil seal
75	lock clip
76	governor spring
77	governor arm bolt M6x21
78	regulating arm
79	throttle return spring
80	governor rod
81	speed control assy
82	washer
83	flange bolt M6x12
84	Exhaust gasket
85	Muffler joint pipe
86	Spring washer
87	Flange bolt