



Number	Name
1	SCREW 5*16
2	WASHER
3	O-RING 16*1.7
4	EXHAUST COVER
5	WASHER
6	SCREW 6*30
7	WASHER #6
8	Cylinder CAP
9	GASKET
10	WASHER
11	Seal,Air/STOPPER
12	FEEDER SPRING
13	O-RING 40*2.65
14	O-RING 56.7*2.9
15	FIRING VALVE PISTON
16	WASHER
17	Seal,Air/STOPPER
18	O-RING 44.7*3.5
19	Piston head
20	DRIVER BLADE
21	O-RING 80*2.65
22	Spacer
23	O-RING 54*3
24	CYLINDER
25	BUMPER
26	NOZZLE
27	O-RING 16*1.8
28	O-RING 19*2.4
29	Trigger Valve Guide
30	O-RING 5.6*1.9
31	AIR PLUG
32	O-RING 8.2*1.78

Number	Name
33	Trigger Valve Guide
34	O-RING 2.3*1.4
35	FEEDER SPRING
36	Remote Core
37	SEAL, AIR
38	FLAKE
39	FEEDER SPRING
40	RELEASE CATCH
41	Prevent fall frame B
42	Prevent fall frame B
43	SPRING PIN 3*30
44	Body
45	PIN
46	RELEASING BLADE
47	SPRING PIN 3*17
48	PIN 3*14
49	TRIGGER
50	FEEDER SPRING
51	TRIGGER
52	WASHER
53	SCREW 4*8
54	SPACER
55	HANDLE GRIP
56	SCREW 6*20
57	TAIL COVER
58	TRIGGER VALVE SET
59	SCREW 4*10
60	WASHER #4
61	Nut M6
62	Prevent fall frame A
63	Prevent fall frame A
64	DRIVER GUIDE

Number	Name
65	SCREW 5*20
66	DRIVER GUIDE COVER
67	SCREW 5*12
68	Pusher
69	STOPPER
70	Spring Holder
71	STOPPER
72	Magazine Support
73	NAIL TANK
74	Steel Bar
75	FEEDER SPRING
76	CLICK LEVER
77	FEEDER SPRING
78	SPRING PIN 3*17
79	Tail Cover
80	SCREW 5*10
81	SCREW 4*8
82	UPPER MAG
83	PISTON SET
84	CYLINDER SET
85	MAGAZINE SET