



Number	Name
1	Socket Cable
2	Safety Valve
3	Pressured Guage,50
4	Control Switch
5	Pressured Guage,40
6	Extend Conector
7	Oil & Water Filter
8	Ball Valve
9	Nut,Rubber Sustain,Tank
10	Bolt,Rubber Sustain,Tank
11	Rubber Sustain,Tank
12	Drain Valve
13	Air Tank
14	Nut,Wheel
15	Rubber Wheel ,6 Inch
16	Bolt,Wheel
17	Single Way Valve
18	Pressured Pipe
19	Solenoid valves
20	Box Top, Capacitance
21	Wiring Terminal
22	AC Circuit Breaker
23	Nut,M8
24	Capacitance
25	Box Bottom, Capacitance
26	Circuit Breaker
27	Screw,Capacitance Box
28	Wire,Circuit Breaker
29	Wire-1,Control Switch
30	Wire-2,Control Switch
31	Nut,Stator
32	Crankcase,Left

Number	Name
33	Stator
34	Bearing,6203
35	Rotor
36	Crankcase,Right
37	Rubber Sustain,Motor
38	Nut,Rubber Sustain,Motor
39	Bolt,Stator
40	Bearing,6006
41	Crankshaft
42	Screw,Crankshaft
43	Cool Fan
44	Clip,Cool Fan
45	Screw,Motor Cover
46	Cover
47	Bolt,Cylinder Head
48	Muffler
49	Cylinder Head
50	Elbow
51	Gasket, Cylinder Head
52	Screw,Valve Disc
53	Limited Block
54	Valve Disc
55	Valve Plate
56	Intake Pressure Plate
57	Sealing,Valve Plate
58	Screw,Pressure Plate
59	Pressure Plate
60	Sealing Cup
61	Cylinder
62	Rod
63	Bolt,Rod