



Number	Name
1	HANDLE
2	SCREW
3	FLOAT SWITCH
4	PROTECT COVER
5	SCREW
6	CABLE
7	SCREW
8	SCREW
9	UPPER PUMP COVER
10	CAPACITOR
11	O RING
12	UPPER BEARING BASE
13	BEARING
14	ROTOR
15	BEARING
16	MOTOR STATOR
17	MECHANICAL SEAL
18	O RING
19	SCREW
20	MOTOR COVER
21	OIL SEAL
22	SCREW
23	O RING
24	IMPELLER
25	WASHER
26	SCREW
27	PUMP BODY
28	FILTER MESH
29	SCREW