


#### **INSTRUCTION MANUAL**

## USB INTELLIGENT CHARGING LANTERN RH-4250









### **SCOPE OF APPLICATION**

Apply to Adventure, Patrol, Camping, Climbing, Mobile charger, Emergency for family blackout, Warning, rescue, Relief and so on.

### **SPECIFICATION**

Datta	I
Battery	2 *18650 3.7V- 3600mAh Li-ion battery
Material	ABS, PC
Product size	250*125*175mm
Product weight	850gr
Accessories	Battery charger, USB cable, Strap

### **FUNCTION AND DIAGRAM FORM**

# ■THE FRONT LIGHT ROCKER SWITCH CONTROL (HIGH-OFF-LOW)

- High-power: 600LM Switch on the " "

Run Time: 2 Hours Distance: 1000m

- Low-power: 280LM Switch on the "=" Run Time: 5 Hours, Distance: 500m



# ■THE SIDE WHITE LIGHT CONTROL BY THE YELLOW SWITCH (HIGH- LOW -OFF)

12 pcs white LED

High: 100 LM

Runtime: 6 Hrs.

Low: 50 LM

Runtime: 12 Hrs.



# ■THE SIDE WARNING LIGHT CONTROL BY THE RED SWITCH (FLASH – OFF)


20 pcs red LED

- Flash frequency 2.2HZ

Runtime: 48 Hrs



### •FUNCTION OF THE TAIL





Ensure charge it in time when last indicator light begins to flash. One of indicator lights is flashing during charging until full charge.

### **BATTERY CHARGER**

#### ■INPUT POWER USB STANDARD CHARGER 5V 0.5 ~ 1 A

Input :5V/0.5-1.0A
Output Parameters 5V/1.5A
This Product designed with USB charging



#### **■INPUT WAY**

Solar power, Computer, Mobile charger, Battery Charger







### **USING INSTRUCTION**

- 1. Please ensure charge 6-7 Hrs before first time use.
- 2. Please don't light eyes, it may hurt eyes.
- 3. Don't put it in wet place.

- 4. Please turn off the light during charging in order to avoid battery damaged.
- 5. Please ensure make a full charge every 3 months.

### **A** WARNING!

- Please don't put in the water to avoid damage.
- Please don't put in the fire to avoid explode.