


VACUUM SUCTION CUP WITH PRESSURE GUAGE 200Kg RH-9933






TECHNICAL SPECIFICATIONS

Model	RH-9933
Load capacity	200Kg
Pad size	200mm
Pad material	rubber
Body material	PA6
Dimention	200x200x85mm
Supplied in	BMC
Includes	Sealing Ring, Gasket, Hook Tools

PART LIST





GENERAL SAFETY RULES



WARNING!

Before operating this appliance, please ensure that you read & understand all the instructions that apply to it, as failure to comply with these instructions may result in personal injury to other person, Please ensure that any replacement parts or accessories used with this appliance are correctly and/or securely fitted before use.


INSTALLATION AND OPERATION INSTRUCTION

Before installing and using te product, please read all the instructions in the manual and keep the manual properly


PAY ATTENTION TO CLEANING

AIR OUTLET NEED TO AVOID ENTERING ASH AND WATER.


■PAY ATTENTION TO CLEAN SURFACE OF THE SUCTION CUP BEFORE USE.








Tile surface with water, oil or glue



Clean tile surface



Tile surface clean and dry




POST-USE STORAGE



ATTENTION!


Do not put it in tile glue, mud and other bad environments, so as not to damage or affect the normal use of the product.



Clean the surface of the suction




Cover with protective cover




Save when finished




REMEDIAL MEASURES IF ASH OR WATERENTERS ACCIDENTALLY



Pull out the hand pressure pump slowly



After cleaning the hand pressure pump, grease can be applied appropriately



Clean the tank



USAGE (CERAMIC TILE GLASS SERIES)

Glass and tiles with clean, smooth surfaces.

Do not use rough surface and uneven objects, such not according to the instructions, the company will not be responsible for any problems Please read the instructions for detalis.

