


Number	Name
1	Decoration case
2	Top cover
3	Handle(long)
4	Pump & motor copper
5	Base cover
6	Right cable reel baffle
7	left cable reel baffle
8	cable reel
9	wheels
10	left wheel cover
11	Right wheel cover
12	left wheel shaft
13	Right wheel shaft
14	Switch box cover
15	Switch
16	Switch box
17	switch joint
18	switch knob
19	Coil plate
20	Two way pressure plate
21	Reel handle shaft
22	High pressure tube pressure block
23	Reel left shell
24	Reel right shell
25	Reel handle
26	Handle bracket shaft
27	Handle bracket
28	spray gun handle

Number	Name
29	gun lance
30	gun nozzle
31	5M high pressure hose
32	soap bottle
33	Water inlet joint
34	gun hook
35	1/2HPC connector
36	Turbo nozzle

PUMP & Motor list



Number	Name	Number	Name
1	Screw	34	Gearwheel
2	spring gasket	35	transmission shaft
3	flat gasket	36	O ring
4	Pump cover	37	Cylinder gasket
5	seal	38	Cylinder
6	General valve spring	39	oil seal ring
7	Valve core	40	Bearing
8	O ring	41	Cam
9	O ring	42	flat gasket
10	O ring	43	spring gasket
11	General valve seat	44	Screw
12	Valve cover	45	Thrust bearing
13	O ring	46	Screw
14	Valve plates	47	Rear cover
15	valve spring	48	Micro switch
16	valve seat	49	push arm
17	pump	50	overflow valve plug
18	Y water seal	51	O ring
19	Screw	52	O ring
20	spring gasket	53	Retaining ring
21	flat gasket	54	overflow valve spring
22	guide ring	55	push rod
23	Oil seal	56	push rod seat
24	Plunger frame	57	O ring
25	O ring	58	O ring
26	Plunger spring	59	push rod seat cover
27	Plunger	60	O ring
28	Plunger spring seat	61	top cover
29	Screw	62	inner wire
30	spring gasket	63	Connector A
31	flat gasket	64	Connector A gasket
32	motor	65	filter
33	Bearing	66	screw