


Ronix[®]

Premium Quality

BOHRHAMMER 26mm 2723



www.ronixtools.com



TECHNISCHE DATEN

Modell	2723
Leistung	800W
Spannung	220-240V
Frequenz	50-60Hz
Bohrfuttertyp	SDS Plus
Schlagenergie	3.2J
Max. Kapazität in Holz	30mm
Max. Kapazität in Stahl	13mm
Max. Kapazität in Beton	26mm
Leerlaufdrehzahl	0-1300U/min
Max. Schlagzahl	0~5500BPM
Gewicht	2.8Kg
Geliefert in	BMC
Enthält	1 Stück 8 mm Bohrer 1 Stück 10 mm Bohrer 1 Stück 12 mm Bohrer 1 Stück Spitze 1 Stück Flachmeißel 1 Satz Kohlebürsten 1 Stück Tiefenmesser.

GERÄTEKOMPONENTEN






Fig.C




FIG.D

WICHTIGE SICHERHEITSHINWEISE

SICHERHEITSWARNUNGEN

ALLGEMEINE SICHERHEITSHINWEISE FÜR ELEKTROWERKZEUGE

Lesen Sie alle Sicherheitshinweise und Anweisungen. Nichtbefolgung der Warnungen und Anweisungen kann zu elektrischem Schlag, Feuer und/oder schweren Verletzungen führen.

BEWAHREN SIE ALLE WARNUNGEN UND ANWEISUNGEN FÜR DIE ZUKUNFT AUF.

Der Begriff "Elektrowerkzeug" in den Warnungen bezieht sich auf Ihr netzbetriebenes (kabelgebundenes) Elektrowerkzeug oder Ihr akkubetriebenes (kabelloses) Elektrowerkzeug.

1- ARBEITSBEREICHSICHERHEIT

a) Halten Sie den Arbeitsbereich sauber und gut beleuchtet. Unordentliche oder dunkle Bereiche führen zu Unfällen .

- b) Betreiben Sie Elektrowerkzeuge nicht in explosionsgefährdeten Atmosphären, wenn brennbaren Flüssigkeiten, Gasen oder Staub dabei sind. Elektrowerkzeuge erzeugen Funken, die den Staub oder die Dämpfe entzünden können.
- c) Halten Sie Kinder und Zuschauer während des Betriebs von Elektrowerkzeugen fern. Ablenkungen können dazu führen, dass Sie die Kontrolle verlieren.

2- ELEKTRISCHE SICHERHEIT

- a) Die Stecker des Elektrowerkzeugs müssen zur Steckdose passen. Modifizieren Sie den Stecker niemals auf irgendeine Weise. Verwenden Sie keine Adapterstecker für geerdete Elektrowerkzeuge. Unveränderte Stecker und passende Steckdosen verringern das Risiko eines elektrischen Schlags.
- b) Vermeiden Sie den Körperkontakt mit geerdeten Oberflächen wie Rohren, Heizkörpern, Herden und Kühlschränken. Wenn Ihr Körper geerdet ist, besteht ein erhöhtes Risiko für einen elektrischen Schlag.
- c) Setzen Sie Elektrowerkzeuge nicht Regen oder feuchten Bedingungen aus. Das Eindringen von Wasser in ein Elektrowerkzeug erhöht das Risiko eines elektrischen Schlags.
- d) Missbrauchen Sie das Kabel nicht. Verwenden Sie das Kabel niemals zum Tragen, Ziehen oder Ausstecken des Elektrowerkzeugs. Halten Sie das Kabel von Hitze, Öl, scharfen Kanten oder beweglichen Teilen fern. Beschädigte oder verwickelte Kabel erhöhen das Risiko eines elektrischen Schlags.
- e) Verwenden Sie im Freien eine Verlängerungsschnur, die für den Außenbereich geeignet ist, wenn Sie ein Elektrowerkzeug im Freien verwenden. Die Verwendung einer für den Außenbereich geeigneten Schnur verringert das Risiko eines elektrischen Schlags.
- f) Wenn der Betrieb eines Elektrowerkzeugs an einem feuchten Ort unvermeidlich ist, verwenden Sie eine mit einem Fehlerstromschutzschalter (RCD) geschützte Stromquelle. Die Verwendung eines RCD verringert das Risiko eines elektrischen

Schlags.

3- PERSÖNLICHE SICHERHEIT

a) Bleiben Sie wachsam, achten Sie darauf, was Sie tun, und verwenden Sie gesunden Menschenverstand beim Betrieb eines Elektrowerkzeugs. Verwenden Sie ein Elektrowerkzeug nicht, wenn Sie müde sind oder unter dem Einfluss von Drogen, Alkohol oder Medikamenten stehen. Ein Moment der Unaufmerksamkeit beim Betrieb von Elektrowerkzeugen kann zu schweren persönlichen Verletzungen führen.

b) Verwenden Sie persönliche Schutzausrüstung. Tragen Sie immer einen Augenschutz. Schutzausrüstung wie Staubmaske, rutschfeste Sicherheitsschuhe, Schutzhelm oder Gehörschutz, die für die jeweiligen Bedingungen geeignet sind, verringern persönliche Verletzungen.

c) Verhindern Sie unbeabsichtigtes Starten. Stellen Sie sicher, dass der Schalter in der Aus-Position ist, bevor Sie das Elektrowerkzeug an die Stromquelle und/oder den Akkupack anschließen, das Werkzeug aufnehmen oder tragen. Das Tragen von Elektrowerkzeugen mit dem Finger am Schalter oder das Einschalten von Elektrowerkzeugen, bei denen der Schalter eingeschaltet ist, birngt Gefahren mit.

d) Entfernen Sie jeden Einstellschlüssel oder Schraubenschlüssel, bevor Sie das Elektrowerkzeug einschalten. Ein Schlüssel, der an einem drehenden Teil des Elektrowerkzeugs befestigt ist, kann zu persönlichen Verletzungen führen.

e) Überschreiten Sie nicht Ihre Reichweite. Halten Sie jederzeit einen sicheren Stand und Gleichgewicht. Dies ermöglicht eine bessere Kontrolle des Elektrowerkzeugs in unerwarteten Situationen.

f) Kleiden Sie sich angemessen. Tragen Sie keine lockere Kleidung oder Schmuck. Halten Sie Ihre Haare, Kleidung und Handschuhe von beweglichen Teilen fern. Lockere Kleidung, Schmuck oder langes Haar können in beweglichen Teilen eingeklemmt werden.

4- ELEKTROWERKZEUG VERWENDUNG UND PFLEGE

a) Erzwingen Sie das Elektrowerkzeug nicht. Verwenden Sie das richtige Elektrowerkzeug für Ihre Anwendung. Das richtige Elektrowerkzeug erledigt die Aufgabe besser und sicherer in dem für das es entworfen wurde.

b) Verwenden Sie das Elektrowerkzeug nicht, wenn der Schalter es nicht ein- und ausschaltet. Jedes Elektrowerkzeug, das nicht mit dem Schalter gesteuert werden kann, ist gefährlich und muss repariert werden.

c) Trennen Sie den Stecker von der Stromquelle und/oder den Akkupack vom Elektrowerkzeug, bevor Sie Einstellungen vornehmen, Zubehör wechseln oder Elektrowerkzeuge aufbewahren. Solche vorbeugenden Sicherheitsmaßnahmen verringern das Risiko, das Elektrowerkzeug versehentlich zu starten.

d) Lagern Sie unbenutzte Elektrowerkzeuge außerhalb der Reichweite von Kindern und lassen Sie Personen, die mit dem Elektrowerkzeug oder diesen Anweisungen nicht vertraut sind, das Elektrowerkzeug nicht bedienen. Elektrowerkzeuge sind in den Händen ungeschulter Benutzer gefährlich.

e) Warten Sie Elektrowerkzeuge. Überprüfen Sie Fehlausrichtung oder Blockierung beweglicher Teile, Bruch von Teilen und andere Zustände, die den Betrieb des Elektrowerkzeugs beeinträchtigen können. Wenn beschädigt, lassen Sie das Elektrowerkzeug vor der Verwendung reparieren. Viele Unfälle werden durch schlecht gewartete Elektrowerkzeuge verursacht.

f) Halten Sie Schneidwerkzeuge scharf und sauber. Ordentlich gewartete Schneidwerkzeuge mit scharfen Schneidkanten neigen weniger dazu, sich zu verhaken, und sind leichter zu kontrollieren.

g) Verwenden Sie das Elektrowerkzeug, Zubehör und Werkzeugbits usw. gemäß diesen Anweisungen unter Berücksichtigung der Arbeitsbedingungen und der auszuführenden Arbeiten. Die Verwendung des Elektrowerkzeugs für andere als die vorgesehenen Operationen kann zu gefährlichen Situationen führen.

5- SERVICE

Lassen Sie Ihr Elektrowerkzeug von einer qualifizierten Fachkraft warten und verwenden Sie nur identische Ersatzteile. Dadurch wird die Sicherheit des Elektrowerkzeugs gewährleistet.

SICHERHEITSWARNUNGEN

Die folgenden Symbole werden in der Bedienungsanleitung oder auf dem Produkt verwendet:



Lesen Sie die Bedienungsanleitung.



Bezeichnet das Risiko von Personenschäden, Lebensverlust oder Beschädigung des Werkzeugs bei Nichtbeachtung der Anweisungen in dieser Anleitung.



Risiko eines elektrischen Schlags.



Entfernen Sie sofort den Netzstecker aus der Steckdose, wenn das Netzkabel beschädigt ist, und während der Reinigung und Wartung.



Tragen Sie immer einen Augenschutz!



Tragen Sie Gehörschutz.



Tragen Sie Sicherheitshandschuhe.

ZUSÄTZLICHE SICHERHEITSWARNUNGEN FÜR BOHRHÄMMER

- a) Tragen Sie Gehörschützer. Lärmbelastung kann zu Hörverlust führen.
- b) Verwenden Sie bei Bedarf den Zusatzgriff. Der Verlust der Kontrolle kann zu persönlichen Verletzungen führen.
- c) Halten Sie das Elektrowerkzeug an isolierten Griffoberflächen, wenn

Sie eine Operation durchführen, bei der das Schneidzubehör versteckte Verkabelung oder sein eigenes Kabel berühren kann. Wenn das Schneidzubehör einen "lebenden" Draht berührt, können freiliegende Metallteile des Elektrowerkzeugs "lebendig" werden und dem Bediener einen elektrischen Schlag verursachen.

ELEKTRISCHE SICHERHEIT

Beim Gebrauch von Elektromaschinen sollten Sie stets die geltenden Sicherheitsvorschriften in Ihrem Land beachten, um das Risiko von Feuer, elektrischem Schlag und persönlichen Verletzungen zu reduzieren. Lesen Sie die folgenden Sicherheitshinweise sowie die beiliegenden Sicherheitsanweisungen.



Überprüfen Sie immer, ob die Spannung der Stromversorgung mit der auf dem Typenschild angegebenen Spannung übereinstimmt.



Klasse-II-Maschine - Doppelte Isolierung - Sie benötigen keinen geerdeten Stecker. Wenn der Betrieb eines Elektrowerkzeugs an einem feuchten Ort unvermeidlich ist, verwenden Sie eine mit einem Fehlerstromschutzschalter (RCD) geschützte Stromquelle. Die Verwendung eines RCD verringert das Risiko eines elektrischen Schlags.

ERSETZEN VON NETZKABELN ODER STECKERN

Wenn das Netzkabel beschädigt ist, muss es vom Hersteller, seinem Kundendienst oder ebenso qualifizierten Personen ersetzt werden, um Gefahren zu vermeiden.

VERWENDUNG VON VERLÄNGERUNGSKABELN

Verwenden Sie ausschließlich zugelassene Verlängerungskabel, die für die Leistung des Geräts geeignet sind. Die Mindestkernstärke beträgt 1,5 mm. Wenn Sie ein Kabeltrommel-Verlängerungskabel verwenden, rollen Sie es immer vollständig aus.

Schalten Sie das Gerät sofort aus, wenn:

- Es zu übermäßigem Funkenflug der Kohlebürsten kommt.
- Der Netzstecker, das Netzkabel oder das Netzkabel beschädigt ist.
- Der Schalter defekt ist.
- Rauch oder Geruch nach verbrannter Isolierung auftritt.

MASCHINENINFORMATIONEN

BESTIMMUNGSGEMÄSSE VERWENDUNG

- Dieser Bohrhämmer ist zum Bohren von Löchern in Mauerwerk wie Ziegel, Beton und ähnlichem Material vorgesehen. Darüber hinaus kann die Maschine in Kombination mit den mitgelieferten SDS-Kaltmeißeln als Abbruchhämmer verwendet werden. Die Maschine ist keinesfalls für andere Zwecke vorgesehen. Vibrationspegel.
- Die Verwendung des Werkzeugs für unterschiedliche Anwendungen oder mit verschiedenen oder schlecht gewarteten Zubehörteilen kann das Expositionsrisiko erheblich erhöhen. - Die Zeiten, in denen das Werkzeug ausgeschaltet ist oder läuft, aber tatsächlich keine Arbeit verrichtet, können das Expositionsrisiko erheblich verringern. Schützen Sie sich vor den Auswirkungen von Vibrationen, indem Sie das Werkzeug und sein Zubehör warten, Ihre Hände warm halten und Ihre Arbeitsabläufe organisieren.

WARTUNG

Bevor Sie mit der Reinigung und Wartung beginnen, schalten Sie die Maschine immer aus und ziehen Sie den Netzstecker aus der Steckdose. Reinigen Sie die Gehäuse der Maschine regelmäßig mit einem weichen Tuch, vorzugsweise nach jeder Verwendung. Stellen Sie sicher, dass die Lüftungsöffnungen frei von Staub und Schmutz sind. Hartnäckigen Schmutz entfernen Sie mit einem weichen Tuch, das mit Seifenlauge befeuchtet ist. Verwenden Sie keine Lösungsmittel wie Benzin, Alkohol oder Ammoniak. Solche Chemikalien können die Kunststoffkomponenten beschädigen.

DEFEKTE


Die Maschine sollte regelmäßig auf folgende mögliche Defekte überprüft und gegebenenfalls repariert werden:

- Beschädigtes Netzkabel.
- Defekter Ein-/Ausschalter.
- Kurzschluss.
- Beschädigte bewegliche Teile

Ronix[®]

Premium Quality

ROTARY HAMMER 26mm 2723



TECHNICAL SPECIFICATION

Model	2723
Power	800W
Voltage	220-240V
Frequency	50-60Hz
Chuck Type	SDS Plus
Impact Energy	3.2J
Max Capacity in Wood	30mm
Max Capacity in Steel	13mm
Max Capacity in Concrete	26mm
No-load Speed	0~1300RPM
Max Impact Rate	0~5500BPM
Weight	2.8Kg
Supplied in	BMC
Includes	1pc 8mm drill bit 1pc 10mm drill bit 1pc 12mm drill bit 1pc point chisel 1pc flat chisel 1set carbon brush 1pc Depth gauge

PART LIST






Fig.C




FIG.D

IMPORTANT SAFETY INSTRUCTIONS

SAFETY ALERT SYMBOLS

GENERAL POWER TOOL SAFETY WARNINGS

Read all safety warnings and all instructions.

Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE.

The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

1- WORK AREA SAFETY

- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks

which may ignite the dust or fumes.

c- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2- ELECTRICAL SAFETY

a- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.

b- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.

c- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.

d- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

e- When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

f- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

3- PERSONAL SAFETY

a- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.

b- Use personal protective equipment. Always wear eye protection. Protective equipment

such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

c- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.

Carrying power tools with your finger on the switch or energizing power tools that have the switch on invites accidents.

d- Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

e- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.

f- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.

4- POWER TOOL USE AND CARE

a- Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b- Do not use the power tool if the switch does not turn it on and off. Any power tools that cannot be controlled with the switch is dangerous and must be repaired.

c- Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.

d- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

e- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

f- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
g- Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

5- SERVICE

Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

SAFETY WARNINGS

The following symbols are used in the user manual or on the product:



Read the user manual.



Denotes risk of personal injury, loss of life or damage to the tool in case of non observance of the instructions in this manual.



Risk of electric shock



Immediately remove the mains plug from the mains if the mains cable becomes damaged and during cleaning and maintenance.



Always wear eye protection!



Wear hearing protection.



Wear safety gloves.

■ ADDITIONAL SAFETY WARNINGS FOR ROTARY HAMMERS

- a- Wear ear protectors. Exposure to noise can cause hearing loss.
- b- Use auxiliary handle(s), if supplied with the tool. Loss of control can cause personal injury.
- c- Hold power tool by insulated gripping surfaces, when performing an operation where the cutting accessory may contact hidden wiring or its own cord. Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

ELECTRICAL SAFETY

When using electric machines always observe the safety regulations applicable in your country to reduce the risk of fire, electric shock and personal injury. Read the following safety instructions and also the enclosed safety instructions.



Always check that the voltage of the power supply corresponds to the voltage on the rating plate label.



Class II machine - Double insulation - You don't need any earthed plug.

If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

REPLACEMENT OF POWER CORDS OR PLUGS

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

USE OF EXTENSION LEADS

Only ever use approved extension leads that are suitable for the power rating of the machine. The minimum core thickness is 1.5mm. Whenever using a reel extension lead, always fully unroll the lead.

Immediately switch off the machine when:

- Excessive sparking of the carbon brushes.
- Interruption of the mains plug, mains lead or mains lead damage.
- Defect switch.
- Smoke or stench of scorched isolation.

MACHINE INFORMATION

INTENDED USE

This rotary hammer is intended for drilling holes in masonry such as brick, concrete and similar material. Furthermore, the machine can be used as a demolition hammer in combination with the SDS cold chisels provided. The machine is on no account intended for other purposes.

Vibration level

- Using the tool for different applications, or with different or poorly maintained accessories, may significantly increase the exposure level.
- The times when the tool is switched off or when it is running but not actually doing the job, may significantly reduce the exposure level.

Protect yourself against the effects of vibration by maintaining the tool and its accessories, keeping your hands warm and organizing your work patterns.

OPERATING

Hammer drills require very little operator pressure. Excessive pressure on the tool can lead to unnecessary overheating of the motor; and burning of the driven tool. It also may happen the drill bit deforms and cannot be removed from the machine again.

SIDE HANDLE

Fig.A

The side handle (5) can be rotated 360° around the drill head, enabling safe and comfortable operation for both left and right-handed users.

- Loosen the handgrip by turning it anticlockwise.

- Rotate the handgrip to the desired position.
- Retighten the handgrip in the new position by turning it clockwise.

EXCHANGING AND REMOVING DRILL BITS

Fig.A- B



Before exchanging bits, first remove the power plug from the wall socket.



Inspect bits regularly during use. Blunt bits should be re-sharpened or replaced.



Lightly oil the bit shaft before inserting it into the chuck.

- SDS drills can be inserted by pushing the drill into the chuck until a click can be heard. If needed rotate the SOS drill a little to ensure the keyway in the bit fits the chuck well.
- To remove the SOS drill, slide the locking sleeve (6) to the rear and remove the SOS drill while keeping the sleeve (6) in this position.

SETTING DEPTH STOP Fig.A

- The depth stop ruler can be added to the side handle by pushing the depth stop button (8).
- Keep pushing the depth stop button (8) and insert the depth stop ruler (7) through the hole on the side handle ring.
- Slide the ruler to the desired depth.
- Loosen the depth stop button (8).

THE ON/OFF SWITCH Fig.A

- Switch the machine on by pressing the on/Off switch (2). When releasing the on/Off switch (2) the machine will turn off.
- The rotation-speed can be continuously adjusted by pressing the on/ Off switch (2) deeper or less deep.

■ Lock-on button Fig.A

- Lock the on/Off switch (2) by pressing the on/ Off switch (2) and then pressing the lock-on button (3).
- Release the switch-lock by shortly pressing the on/Off switch (2) again.

Switching the direction of rotation Fig.A.

- Direction of rotation counter-clockwise: shift left/right switch (1.1) to "→".
- Direction of rotation clockwise: shift left/right switch (1.1) to "←".

Function selection switch

In order to avoid damage to the machine, adjusting the function selection switch (4) shall only be done when machine is not running. Fig. C

FIG.D

The correct position of the function selection switch (5) for each function is shown in the pictures in fig. D. Always make sure the function switch clicks in the desired position.

A- Drilling (without hammer function): for drilling in several materials.

B- Hammer Drilling (with hammer function): for drilling in masonry such as brick, concrete and similar material.

C- Chisel angle adjustment: for changing the angle of the chisel. When set under right angle switch back to position D. before using the tool.

D- Chipping (chisel function): for chipping and small demolition jobs.

USER TIPS

Always use the machine with the side handle firmly anchored in place

- you will not only work with more comfort, you will also work with more precision.

CAUTION!

drills and chisels can get very hot.

DRILLING AND HAMMER DRILLING (function A and B)

- For large holes, for instance in very hard concrete, start using a smaller bit for pilot drilling first, then drill to nominal size.
- Hold the machine firmly with 2 hands. Be aware the drill can jam and because of that machine might suddenly turn (especially when drilling deep holes).
- Do not apply a lot of pressure on the machine, let the machine do the work.

Chipping in concrete and brick (function C & D)

- It is also possible to use the machine for chipping.
 - only change the function when the motor has come to a standstill.
- Do not apply a lot of pressure on the machine, let the machine do the work.

MAINTENANCE

Before cleaning and maintenance, always switch off the machine and remove the mains plug from the mains.


Clean the machine casings regularly with a soft cloth, preferably after each use. Make sure that the ventilation openings are free of dust and dirt. Remove very persistent dirt using a soft cloth moistened with soapsuds. Do not use any solvents such as gasoline, alcohol, ammonia etc. Chemicals such as these will damage the synthetic components.


DEFECTS

The machine should be regularly inspected for the following possible defects and repaired if necessary.

- Damage to power cord.
- Broken on/off trigger assembly.
- Short circuiting.
- Damaged moving parts.









www.ronixtools.com